



SK NÁVOD NA INŠTALÁCIU VINYLOVEJ TAPETY

Inštalácia tapiet by sa mala vykonávať pomocou profesionálnych nástrojov, ako sú: nôž, tmel a valček alebo štetec na nanášanie lepidla a základného náteru.

PRÍPRAVA

Kvalita steny

Podklad by mal byť suchý, čistý, bez prachu, dokonale hladký a odolný. Povrch steny sa nesmie drobiť. V prípade drobiacich sa podkladov odstráňte nestabilné časti a medzery vyplňte tvrdým tmelom. Natretú stenu treba dôkladne umyť odmasťovacím prostriedkom. Teplota v miestnosti by nemala byť nižšia ako 10°C.

! Tapeta nerovnosti steny nezakryje, často ich zvýrazní.

Podklad

Povrch steny by mal byť dôkladne natretý penetračným náterom. Penetrujeme všetky typy stien: sadrokartónové, omietkové, maľované. Pri svetlých farbách tapiet sa odporúča vybieliť stenu nanesením základného náteru, následne bielej farby a ďalšej vrstvy základného náteru. Po nanesení základného náteru sa odporúča stenu zmatniť.

Lepidlá

Odporúča sa použiť lepidlo Gaudia. Pred použitím si prečítajte návod na použitie na nádobe s lepidlom.

Všeobecné pravidlá

Pred pokusom o inštaláciu tapety na stenu sa odporúča naplánovať inštaláciu. Neinštalujte tapety z rôznych výrobných šarží na rovnakú stenu. Ak si objednáte niekoľko roliek tapety, usporiadajte role v číselnom poradí, od najnižšej po najvyššiu! Vzostupné čísla kotúčov označujú navrhované poradie aplikácie. Novú rolku tapety otvorte až po minúti predchádzajúcej.

! Tapety použité na projekt by mali mať rovnakú výrobnú šaržu.

Rezanie

Tapetové pásy by mali byť rezané o 5-10cm dlhšie ako je výška steny. Rezané pásy očistite ceruzkou v poradí, v akom budú aplikované. Na číslovanie nepoužívajte perá, fixky a pod. Vyznačte si na stenu zvislú čiaru, pozdĺž ktorej bude nanesený prvý pás tapety.

! Pred narezaním tapety na dĺžku skontrolujte, či farba a vzor sú správne a bez chýb

APLIKÁCIA

Lepidlo nanášajte len na stenu, nie na tapetu! Striedavo nanášajte pásiky otáčaním o 180 stupňov (obr. 1).

1.Prekrývajúca sa inštalácia (obr. 2)

Hmotnosť tapety < 600 g (Keira, Rea, Freya, Enya, Ryana). Hmotnosť tapety > 600 g (Chantal).

- Naneste prvú dĺžku obkladu pozdĺž zvislej čiary na stenu.
- Otočte ďalšiu dĺžku o 180 stupňov a naneste ju tak, aby prekrývala prvú dĺžku o 5-10 cm. Celý spoj uhladte.
- Pomocou veľmi ostrého noža prerežte oba prekrývajúce sa listy tapety pozdĺž zvislej línie, od stropu po podlahu.
- Odstráňte odrezané pásy obkladu (aj spoj dĺžky obkladu) a protiahle okraje spojte na tupo.
- Odstráňte prebytočné lepidlo vlhkou handričkou/špongiou, kým nezaschne.

Inštalácia na tupo (obr.3)

Hmotnosť tapety > 600 g (Grace, Grace glossy, Anabel)

- Naneste prvú dĺžku obkladu pozdĺž zvislej čiary na stenu.
- Otočte ďalšiu dĺžku o 180 stupňov a naneste ju tak, aby dve dĺžky vytvorili tupý spoj.
- Oba okraje zarovnajete a uhladte valčekom.
- Prebytočnú dĺžku tapety odstráňte až po aplikovaní 4-5 pásov.

! Tapetu je možné utierať vlhkou (nie mokrou) handričkou z mikrovlákná bez štruktúry.

! Tam, kde sa tapety spájajú, sa odporúča natrieť stenu farbou podobnou farbe tapety.

ZÁRUKA

Technické vlastnosti produktu, ďalej len „predmet záruky“. Vinylová tapeta - vrchná vrstva vinylu na polyesterovom/bavlnenom podklade, chránená špeciálnym náterom. Odolné voči alkoholu a UV žiareniu. Výrobok je vodeodolný.

Všeobecné podmienky záruky kvality

- Výrobca vyhlasuje, že materiál, na ktorý sa vzťahuje táto záruka, bol vyrobený v súlade so zásadami technických znalostí a právnymi predpismi.
- Záručná doba je 24 mesiacov odo dňa kúpy alebo podpísania konečného preberacieho protokolu bez akýchkoľvek výhrad.
- Tapety Gaudia sú určené do vnútorných priestorov a tak by sa aj mali používať.
- Inštaláciu by mala vykonať autorizovaná montážna firma s použitím lepidla Gaudia.
- Pred inštaláciou skontrolujte, či predmet záruky neobsahuje chyby.
- Správne nainštalovaná tapeta sa stáva odolnou 7 dní po inštalácii.

Záruka je poskytovaná na:

- Vodotesný výkon materiálu
- Nenasiakavosť materiálu
- Farebnú stálosť materiálu vystaveného slnečnému svetlu.

Táto záruka sa nevzťahuje na:

- Vyššiu moc
- Bežné roztrhnutie a opotrebovanie predmetu záruky
- Škoda spôsobená vlastníkom projektu, ktorá môže zahŕňať použitie akýchkoľvek chemikálií, čistiacich prostriedkov alebo žieravín na čistenie tapety.

Starostlivosť a údržba tapety:

- Obklad steny čistite utieraním vlhkou (nekvapkajúcou), neštruktúrovanou handričkou z mikrovlákná.
- Nepoužívajte žiadne chemikálie ani domáce čistiace prostriedky (napr. ocot alebo sódu bikarbónu).

EN VINYL WALLCOVERING INSTALLATION INSTRUCTIONS

Install the wallcovering with professional tools, which will include: a utility knife, a trowel, and a roller or brush for applying the adhesive and the primer.

PREPARATIONS

Wall substrate

The substrate shall be dry, clean, free of dust, smooth, and sound. The wall substrate shall not crumble. If the substrate crumbles, remove all detached pieces and fill out the holes flush with a hard filler putty. If the wall was painted, wash it thoroughly with a degreaser. The room temperature must be 10°C or higher.

! The wallcovering will not hide roughness, it will often pronounce it.

Priming

Prime the wall substrate generously with the primer. Every wall substrate type will require priming, including drywall-lined, rendered, builder's finished, and paint coated walls. For light wallcovering colours, it is recommended to whiten the wall by applying the primer, followed by white paint, and another coat of primer. Once primed, the wall is recommended to be dulled.

Adhesives

A Gaudia adhesive for thick wallcoverings is recommended. Read the instructions for use on the adhesive container before use.

General requirements

Before attempting to install the wallcovering, it is recommended to plan the installation. Do not install wallcovering from different production lots on the same wall. If more than one wallcovering roll is ordered for the project, arrange the rolls from the lowest to the highest roll number! The ascending wallcovering roll numbers are the order of installation from rolls. Start each new wallcovering roll once the last one is spent.

! Install the wallcovering from the same production lot on the same wall.

Cutting

Cut the wallcovering roll to match the wall height plus 5-10 cm of length. Number the cut wallcovering lengths with a pencil in the order of installation. Do not apply the numbering with ball pens, felt-tippens, etc. Mark out the vertical line on the wall along which the first length of wallcovering will be applied.

! Before cutting the wallcovering to length verify that the colour and pattern are correct and free of defects.

ADHESIVE BONDING

Apply the adhesive to the wall only! Apply the wallcovering lengths alternately, with every other length rotated by 180 degrees as shown in the figure to the right. (pic. 1).

1. Overlapping installation (pic. 2)

Wallcovering weight < 600 g (Keira, Rea, Freya, Enya, Ryana). Wallcovering weight > 600 g (Chantal).

- Apply the first wallcovering length along the vertical line on the wall.
- Rotate the next length by 180 degrees and apply it overlapping the first length by 5-10 cm. Smooth the whole joint.
- Use a very sharp knife to cut through both overlapping sheets of the wallcovering along the vertical line, from the ceiling to the floor.
- Remove the cut-off strips of the wallcovering (also from underneath the wallcovering length) and make the opposite edges butt-joined.
- Remove excess adhesive with a damp cloth/sponge until dry.

2. Butt-joint installation (pic. 3)

Wallcovering weight > 600 g (Grace, Grace glossy, Anabel)

- Apply the first wallcovering length along the vertical line on the wall.
- Rotate the next length by 180 degrees and apply it so that the two lengths form a butt joint.
- Align both edges straight and smooth them with a roller.
- Remove the overlap along the length once 4 or 5 wallcovering lengths are on the wall.

! Clean the wallcovering by wiping with a damp (non-dripping), untextured microfibre cloth.

! It is recommended to paint the wall along the wallcovering joints in a colour close to the wallcovering colour.

WARRANTY

Technical specification of the product henceforth the "Warranty Object". A vinyl wallcovering consisting of a top vinyl layer, protected with a special coating, and a polyester/cotton backing. Resistant to alcohol and UV. Waterproof and non-water absorbing.

General quality warranty terms and conditions

- The manufacturer declares that the Warranty Object has been manufactured in compliance with good engineering practice and regulations of law.
- The warranty period is 24 months from the date of purchase or the date of signing an unconditional final acceptance report, as applicable.
- The Gaudia wallcoverings are intended for indoor applications and no other application is authorized.
- The wallcoverings shall be installed by an authorized installation contractor, using a Gaudia adhesive.

-Inspect the Warranty Object for defects before installing. The defects on the wall can be verified up to two wallcovering lengths already installed.

-The wallcovering will develop full resistance in 7 days after correct installation.

This warranty is provided for:

- Waterproof performance of the material;
- Non-water absorption of the material;
- Colour fastness of the material exposed to sunlight.

This warranty is not provided for:

- Force majeure;
- Normal tear and wear of the Warranty Object;
- Damage caused by the Project Owner, which may include use of any chemicals, detergents, or corrosives to clean the wallcovering.

Wallcovering care and maintenance:

- Clean the wallcovering by wiping with a damp (non-dripping), untextured microfibre cloth.
- Do not use any chemicals or household cleaning products (e.g. vinegar or baking soda).